


K&D R150 Configurator 360 Manual

Version 1.0



Inhoud

1. General.....	2
2. Accessibility Configurator	2
3. R150 Round conveyor Configurator	2
4. Configuration of the 3D model	3
5. Set Limits	4
6. Options configurator	5

1. General

The K&D Configurator 360 aims to quickly configure 3D models and download them for use in custom 3D designs.

The 3D models can be downloaded as STEP or SAT file.

It is also possible to request an advice or quotation of the configured model.

Standards were assumed when designing the configurator. There are many more options outside the standards. If you want a different belt color, the motor or legs of the support in a different location, shorter side guides, etc., please contact the sales department.


No rights can be derived from the configured models. Upon a quotation request, your configured model will be assessed by Kramer & Duyvis B.V.

2. Accessibility Configurator

The configurator is accessible from the K&D website where no registration or login is required. The direct link to the R150 configurator is <http://www.kramer-duyvis.com/en/configurator-type-r150> . This is a combined KDC, KDZ, R100 and R150 configurator.

3. R150 Round conveyor Configurator

After you have clicked on the link you will be redirected to the Kramer & Duyvis website. If you do not see the configurator immediately, press F5 to refresh the page. The first loading time takes on average 10 to 20 seconds. On the left you will find the input screen by which you can configure the belt conveyor.




1. **Configuration panel**, Control panel, this is open by default. If you have exported a 3D model or have made an Advice / Quotation request, you can call up the configuration screen again via this button.
2. **Export 3D Model**, This allows you to export your configured model to a STEP or SAT file.
3. **Advice / Quotation Request**, if you want advice whether your configured model meets the requirements and / or you want a quote, you can do that via this button. The configured model is then saved so that Kramer & Duyvis can assess it.

4. Configuration of the 3D model

The fully expanded configuration screen looks like this:

<div style="border: 1px solid #ccc; padding: 5px;"> <div style="text-align: right;">Type Conveyor R150 ▼</div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="text-align: left;">▼ Dimensions</div> <div style="text-align: right;">Angle (deg) 90</div> <div style="text-align: right;">Beltwidth (mm) 600</div> <div style="text-align: right;">Outside Radius (mm) 1200</div> <div style="text-align: right;">Inner Radius (mm) 600</div> <div style="text-align: right;">Belt Color Black ▼</div> <div style="text-align: right;">Motor Type MR60 ▼</div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="text-align: left;">▼ R100 - R150 Motor Position</div> <div style="text-align: right;">Counter_Clockwise <input type="checkbox"/></div> <div style="text-align: right;">Drive_Unit_Inside <input type="checkbox"/></div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="text-align: left;">▼ KDC - KDZ Support</div> <div style="text-align: right;">Support <input type="checkbox"/></div> <div style="text-align: right;">Height (mm) 800</div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="text-align: left;">▼ KDC - R100 - R150 Side Guide</div> <div style="text-align: right;">Inner Side Guide <input type="checkbox"/></div> <div style="text-align: right;">Inner Side Guide Height (mm) 100</div> <div style="text-align: right;">Outer Side Guide <input type="checkbox"/></div> <div style="text-align: right;">Outer Side Guide Height (mm) 100</div> </div>



By making a choice from the drop-down menus or changing a value, the 3D model will be adjusted immediately. This takes around 1 to 10 seconds.

This direct adjustment is necessary because further options depend on the choices made.

Not all options are available for the R150 Type.

5. Set Limits

A number of rules have been set in the configurator according to our standards. Outside these standards, more is possible. If you are unable to configure your desired model due to limitations of the standards, please contact the sales department of Kramer & Duyvis B.V.

If you have a 3D Design program such as Autodesk Inventor Professional, you can also adjust the downloaded 3D models.

Below you will find the table with the minimum and maximum values that have been processed in the configurator.

Pay attention! If you enter a value outside the limits, it will be adjusted automatically. Always check the values displayed in the configuration panel before you export the model.

R150 Rules	Minimum (mm)	Maximum (mm)
Angle	25	180
Belt Width	200	1300
Outside Radius	600	2600
Inner Radius	300	1500
Length Profile		5600
Height Inner Guide	50	200
Height Outer Guide	50	200

6. Options configurator

A number of codes are being used in the configurator. Below you will find an explanation of what these codes mean.

The below outlined only explains what is present in this configurator. For more options and further information please visit our website or contact Kramer & Duyvis B.V.

Belt Width

Manual input 200 - 1.300 mm.

Angle

There are no standard angles. The angle can be accurately determined to the millimeter.
Manual input from 25 to 180 degrees.

Belt colors

The following colors are available in the configurator:

- Black
- Blue
- Green
- White

Other colors available upon request.

Motorreductor options (also possible with forced cooling)

- MR60 SEW motorreductor, 230/400V, 50 Hz, IP54